

# NEO - Face the Future



- **Unique** - Horizontal Switches available for Horizontal Decor
- **Stylish** - Ingenious combination of matt and gloss finish along with a fresh look through use of LED technology
- **Convenient** - Switches with soft, luminiscent “locators” to locate the switch in dark
- **Dual Tone Colours** - Standard colours include Grey and White incorporating Blue and White LED respectively



E3033H1EBGS



E3032H1EWWW



E3032H1FWWW



E3032V1EBGS



E3031V1EWWW



E3032V1FWWW

Description	Horizontal Dolly Reference	Unit MRP [₹]	Pack	Vertical Dolly Reference	Unit MRP [₹]	Pack
<b>Grey Switches with Blue LED Indicator</b>						
10AX 250V 1 Gang 1 Way Switch	E3031H1EBGS	1175	1	E3031V1EBGS	1175	1
10AX 250V 1 Gang 2 Way Switch	E3031H2EBGS	1373	1	E3031V2EBGS	1373	1
10AX 250V 2 Gang 1 Way Switch	E3032H1EBGS	1837	1	E3032V1EBGS	1837	1
10AX 250V 2 Gang 2 Way Switch	E3032H2EBGS	2165	1	E3032V2EBGS	2165	1
10AX 250V 3 Gang 1 Way Switch	E3033H1EBGS	2692	1	E3033V1EBGS	2692	1
10AX 250V 3 Gang 2 Way Switch	E3033H2EBGS	3170	1	E3033V2EBGS	3170	1
10AX 250V 4 Gang 1 Way Switch	E3034H1EBGS	3348	1	-	-	-
10AX 250V 4 Gang 2 Way Switch	E3034H2EBGS	3959	1	-	-	-
<b>White Switches with White LED Indicator</b>						
10AX 250V 1 Gang 1 Way Switch	E3031H1EWWW	1140	1	E3031V1EWWW	1140	1
10AX 250V 1 Gang 2 Way Switch	E3031H2EWWW	1315	1	E3031V2EWWW	1315	1
10AX 250V 2 Gang 1 Way Switch	E3032H1EWWW	1819	1	E3032V1EWWW	1819	1
10AX 250V 2 Gang 2 Way Switch	E3032H2EWWW	2106	1	E3032V2EWWW	2122	1
10AX 250V 3 Gang 1 Way Switch	E3033H1EWWW	2574	1	E3033V1EWWW	2574	1
10AX 250V 3 Gang 2 Way Switch	E3033H2EWWW	2986	1	E3033V2EWWW	2986	1
10AX 250V 4 Gang 1 Way Switch	E3034H1EWWW	3271	1	-	-	-
10AX 250V 4 Gang 2 Way Switch	E3034H2EWWW	3876	1	-	-	-
<b>White Switches with White Fluorescent Indicator</b>						
10AX 250V 1 Gang 1 Way Switch	E3031H1FWWW	1134	1	E3031V1FWWW	1134	1
10AX 250V 1 Gang 2 Way Switch	E3031H2FWWW	1278	1	E3031V2FWWW	1278	1
10AX 250V 2 Gang 1 Way Switch	E3032H1FWWW	1811	1	E3032V1FWWW	1811	1
10AX 250V 2 Gang 2 Way Switch	E3032H2FWWW	2113	1	E3032V2FWWW	2113	5
10AX 250V 3 Gang 1 Way Switch	E3033H1FWWW	2568	1	E3033V1FWWW	2568	5
10AX 250V 3 Gang 2 Way Switch	E3033H2FWWW	3028	5	E3033V2FWWW	3028	5
10AX 250V 4 Gang 1 Way Switch	E3034H1FWWW	3312	1	-	-	-
10AX 250V 4 Gang 2 Way Switch	E3034H2FWWW	3908	1	-	-	-

Please contact Customer Care Center for Stockable and Non stockable status of references.

NORMAL STOCK ITEMS

W.E.F. January 25<sup>th</sup>, 2022

# NEO - Face the Future



E3031VBP>GS-OS



E3031VD20>EWWW-OS



E3426/10IS>GS-OS



EH3015/6>GS-OS



E3031TV>GS-OS



E3031RJ5E>WW-OS



E3031USB\_GS



E3031USB\_WW



E3032HDM>GS-OS



E3031EKTH>WW-OS

Description	Horizontal Dolly Reference	Unit MRP [₹]	Pack	Vertical Dolly Reference	Unit MRP [₹]	Pack
<b>Bell Push</b>						
4A 1 Way Horizontal Bell Push Switch	E3031HBP>GS-OS	2449	1	E3031HBP>WW-OS	2399	1
4A 1 Way Vertical Bell Push Switch	E3031VBP>GS-OS	2407	1	E3031VBP>WW-OS	2365	1
<b>DP Switches</b>						
1 Gang Horizontal 20A DP Switch with Blue LED for Grey Switch and White LED for White Switch	E3031HD20EBGS	2038	1	E3031HD20EWWW	1987	1
1 Gang Vertical 20A DP Switch with Blue LED for Grey Switch and White LED for White Switch	E3031VD20>EBGS-OS	1987	1	E3031VD20>EWWW-OS	1919	1
1 Gang 32A DP Rocker Switch with Blue LED for Grey Switch and White LED for White Switch	E3031DR32EBGS	2986	1	E3031DR32EWWW	2876	1
<b>Intermediate Switch</b>						
16AX Intermediate Switch with Blue LED for Grey Switch and White LED for White Switch	E3031VIA>EBGS-OS	3221	1	E3031VIA>EWWW-OS	3094	1
<b>Socket</b>						
15A 1 Gang Switch Socket Outlet Grey with Blue LED for Grey Socket and White LED for White Socket	E3015/15-EBGS-EX	3497	1	E3015/15-EWWW-EX	3396	1
10A International Socket	E3426/10IS>GS-OS	2734	1	E3426/10IS>WW-OS	2616	1
6A 1 Gang Switch Socket Outlet	EH3015/6>GS-OS	2021	1	EH3015/6>WW-OS	1945	1
6/16A 1 Gang Switch Socket Outlet	EH3015/16/6>GS-OS	2826	1	EH3015/16/6>WW-OS	2759	1
<b>Fan Regulators &amp; Dimmers</b>						
1 Gang Fan Control	E3031FRGS	3271	3	E3031FRWW	2959	3
1 Gang Dimmer with Blue LED for Grey Dimmer and White LED for White Dimmer	E3031HD>EBGS-OS	19597	1	E3031HD>EWWW-OS	19404	1
2 Gang Horizontal Dimmer with Blue LED for Grey Dimmer and White LED for White Dimmer	E3032HD>EBGS-OS	34364	1	E3032HD>EWWW-OS	33408	1
<b>Accessories</b>						
1 Gang TV Socket Outlet	E3031TV>GS-OS	1819	1	E3031TV>WW-OS	1774	1
2 Gang TV Socket Outlet	E3032VTV>GS-OS	3547	1	E3032VTV>WW-OS	1830	1
4 Pin 1 Gang Telephone Outlet (CAT 3)	E3031RJ>GS-OS	2113	1	E3031RJ>WW-OS	2005	1
4 Pin 1 Gang 8 Pin Data Outlet (CAT 5E)	E3031RJ5E>GS-OS	5586	1	E3031RJ5E>WW-OS	5384	1
4 Pin 2 Gang Telephone Outlet (CAT 3)	E3032RJ>GS-OS	3774	1	E3032RJ>WW-OS	3547	1
4 Pin Telephone Outlet (CAT 3) + 8 Pin Data Outlet (CAT 5E)	E3032TD>GS-OS	6884	1	E3032TD>WW-OS	6660	1
25A Connection Unit	E3031TB>GS-OS	1600	1	E3031TB>WW-OS	1534	1
1 Gang Blank Plate	E3030X>GS-OS	1033	1	E3030X>WW-OS	986	1
2 Gang Blank Plate	ET3030X>GS-OS	2306	1	ET3030X>WW-OS	2221	1
<b>USB Charger</b>						
1 x 2.1A USB Charger	E3031USB_GS	7408	1	E3031USB_WW	7088	1
1 x 2.1A USB Charger(ISI)	E3031USB_GS_G8	7762	10	E3031USB_WW_G8	7426	10
<b>Hotel Series</b>						
2 Gang "Do Not Disturb" & "Please Clean Up" Combined (Horizontal)	E3032HDM>GS-OS	10625	1	E3032HDM>WW-OS	10297	1
1 Gang "Do Not Disturb" & "Please Clean Up" Combined (Vertical)	E3030VDM>GS-OS	9896	1	E3030VDM>WW-OS	9359	1
1 Gang Bell Push with "Please Clean Up" Combined (Vertical)	E3031VBPM>GS-OS	8117	1	E3031VBPM>WW-OS	7824	1
1 Gang Bell Push with "Do not Disturb" Combined (Vertical)	E3031VBPD>GS-OS	8117	1	E3031VBPD>WW-OS	7824	1
1 Gang Bell Push with "Do Not Disturb" & "Please Clean Up" Combined (Vertical)	E3031VBPDM>GS-OS	8117	1	E3031VBPDM>WW-OS	7824	1
Electronic Key Card Switch (Horizontal)	E3031EKTH>GS-OS	22506	1	E3031EKTH>WW-OS	21911	1
115/240V Shaver Outlet (Vertical)	ET3727V>GS-OS	11680	1	ET3727V>WW-OS	11455	1

Please contact Customer Care Center for Stockable and Non stockable status of references.

NORMAL STOCK ITEMS

W.E.F. January 25<sup>th</sup>, 2022